

Running Board Instructions

7070

2004–2010 Nissan Titan King/Crew Cab
2004-2010 Nissan Armada

(No Drilling Required)

INSTALLATION PACKAGE

| | |
|------------------------|---|
| Running Board | 2 |
| Bracket s | 8 |
| Support Plates | 8 |
| Bolt Pack (Brackets) | 1 |
| Bolt Pack (Boards) | 1 |

Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket
Combination wrench
Safety glasses

Bolt Pack Brackets

| | |
|----------------------|----|
| 8mm x 20mm Hex Bolts | 16 |
| 8mm Flange Nuts | 16 |
| 5/16" Flat washer | 28 |

Bolt Pack Running Boards

| | |
|----------------------------------|----|
| 5/16" x 3/4" Hex Bolt | 16 |
| 5/16" x 3/4" Serrated Flange Nut | 16 |

STEP ONE : Determine proper bracket placement.

1. There are (4) factory 8mm studs on upper rocker panel and (4) factory 8mm holes on lower angled rocker panel on the underside of the vehicle on each side where the brackets need to be placed. Factory black plug must be removed to reveal factory threaded holes.
2. Mount support plate as shown Fig A. Hand tighten 8mm bolt with washer. Next, hand tighten brackets on stud using 8mm nuts Fig B and attach lower portion of bracket with 8mm bolt, washer and nut to support plate.
3. Place board on brackets with bracket mounted in position. Look on underside of board to which channel match up with bracket slots to slide 5/16" bolts down on underside of board so bolt stud will lined up with bracket slots. You will only need one bolt to secure board to each bracket. Two bolts per bracket are supplied if applicable. Loosely hand tighten 5/16" nuts to hold board to brackets
4. Fully tighten all brackets. Adjust board to center on cab front to back and adjust in and out for desired step area. Tighten outside brackets first then inside bracket accordingly. Fully tighten all brackets.

STEP TWO : Board Installation Check.

- 1) Check all bolts to verify completed mounting and tightness. Installation is complete

